


TOTAL HEAD CALCULATION

Total head formula:
 $A + B + \text{FRICTION}$



INSTALLATION

SOLASTAR is designed to be easy and quick to install using unskilled, village level labour and minimal tools. A detailed, easy to follow Installation Manual is enclosed with every SOLASTAR system purchased.



GENERAL ASSEMBLY

